

HCS-3100/3150/3200/3300/3400/3600 series

Laboratory Grade & High RFI Immunity Switch Mode Power Supply with Rotary Encoder Control

User Manual

1. INTRODUCTION

This series of efficient, state-of-the-art Switch Mode Power Supplies (SMPS) feature a small form factor, automatic crossover between Constant Voltage (CV) and Constant Current (CC) modes, three voltage and current presets (for quick access to frequently used settings), remote on/off and remote analogue control of both voltage and current. In addition the HCS-310x, HCS-3150, HCS-320x and HCS-3x00-USB series have a USB port for control of the Power Supply by computer using the supplied PC software or user-written application software under Windows, Linux, Android or on the Mac under OSX.

The power supplies also feature dual action (coarse/fine) rotary encoders with a micro-control unit (MCU) making setting the voltage and current levels smooth, precise and quick. A new feature with this range of power supplies is the precise setting of the current limit without requiring the output terminals be short circuited.

The HCS series power supplies are suitable for a wide range of applications in the laboratory and in research, servicing, telecom, production, field testing and in manual and automated control of a wide range of high power DC devices.

2. WARNING

- Do not use the power supply near water.
- Do not operate or touch the power supply with wet hands.
- Do not open the casing of the power supply when it is connected to ac mains.
- Refer all servicing to qualified service personnel.
- Before replacing the AC fuse located at the AC mains input socket, rectify the cause first.
- Replace the AC fuse only with the same type and rating as the original.
- The maximum voltage on some models is over 60VDC. Avoid touching the output terminal metal contacts.


3. CAUTION

- Always use a grounded three pin (earthed) AC source.
- The unit is for indoor use only.
- Do not operate or place the unit in a humid, dusty, in direct sunlight location or near any heat source.
- Before plugging into the AC mains plug, check the rating label on the back of the unit.
- Do not block any ventilation openings or fan outlets on the unit
- The unit must be used within the specified rating. Exceeding the maximum voltage or current specification loading may cause damage to the power supply.
- The gauge size of the input power cable must be at least 0.75mm² and the total length of power cable must not exceed 3m.
- Always use the supplied USB cable with ferrite core when using computer control. Always disconnect the USB cable when not in use.


4. ENVIRONMENTAL CONDITIONS

- 0~40°C Operating Temperature
- 10~80% Relative Humidity
- Altitude up to 2000m
- Installation category: CAT 2
- Pollution degree: 2
- Mains supply voltage fluctuation up to ±10% of the normal voltage

5. CONTROLS AND INDICATORS



Front



Rear

- (1) LED panel meter V and A display (Volts and Amps) with CV/CC (Constant Voltage/Constant Current) Indicators
- (2) Rear Control Indicator (lights up when using Preset, Remote Control or Set modes)
- (3) Output Voltage Control Knob (press to toggle between course and fine adjustment)
- (4) Output Current Control Knob (press to toggle between course and fine adjustment)
- (5) Power ON/OFF Switch (I=on, O=off)
- (6) Auxiliary Output Terminals, accepts 4mm banana plug (max 5A continuous, protected by resettable fuse)
- (7) Main Output Terminals (red=positive, black=negative)*
- (8) Remote Voltage Sensing Terminals (**HCS-3600 only**)
- (9) Mode Selection Switch (Normal, Preset, Remote Control, Set Modes)
- (10) Preset Recall Selection Switch (P1, P2, P3)
- (11) Remote Control Socket (controls Voltage and Current settings and output on/off)
- (12) Cooling Fan Air Exhaust Outlet and Grill
- (13) AC Mains Input Socket and Fuse (standard IEC 3 pin socket with earth connection)
- (14) USB port for remote computer control (**HCS-310x, 3150, 320x and USB series only**)

*accepts 6mm fork lugs or 4mm banana plugs - the HCS-3600 has gold-plated binding posts and has terminal screws that can be detached, hence eye lugs may be used.

6. CONTROL MODE SELECTION

There are four modes, Normal, Preset, Set and Remote Control modes for the power supply.

Slide the Mode Selection Switch (9) to your desired Mode.

The power supply is factory set to Normal Mode with maximum voltage and current levels. Note, Procon Technology sets the voltage to the minimum value and it is suggested that this should be done to ensure safe operation!

6.1 Normal Mode

The power supply output voltage and current are controlled by the front-panel dual action controls. Push each knob to toggle between coarse and fine adjustment, notice the subtle changes in brightness of related LED display.

Adjust the control to your desired value by using the coarse and fine tuning.

To check the preset voltage or current limit, just turn the Current Knob lightly one step in any direction.

The display will resume its normal brightness, and display the actual Voltage and Current output, after a few seconds once the adjustment is complete.

6.2 Preset Mode

- a. In this mode, the Rear Control Light is turned on to indicate the front panel V and I controls are de-activated.
- b. There are three preset outputs P1/ P2/ P3 at the Recall Selection Switch (10)
- c. The preset values are factory set as shown in the following table.
- d. The user can select the preset values. Refer to section 6.3

Recall No.	Output Voltage	Output Current
P1	5V	Maximum
P2	13.8V	Maximum
P3	HCS-3x00: 15V* HCS-3x02: 25V HCS-3x04: 55V	Maximum

*The HCS-3150 is also set to 15V.

6.3 Set Mode – Enter into the Set Mode by moving Switch (9) to the ‘Set’ position.

The power supply’s output turns off and the programmed V & I preset values are displayed.

6.3.1 To define the preset output P1/ P2/ P3...

- a. Adjust the Recall Switch (10) to the position P1, P2 or P3 which you wish to set.
- b. Adjust the front panel voltage control knob to set the desired voltage value.
- c. Adjust the front panel current control knob to set the desired current limit value.
- d. Repeat the procedure, if desired, for the remaining preset values.
- e. Move Mode Switch (9) from Set to the Preset position to confirm your settings.

6.3.2 To check the P1/P2/P3 values...

All the presets retain their values even if the power supply has been turned off. Always check the output voltage and current Presets before connecting the load. To check the preset values, move Mode Switch (9) to the Set position. Be careful not to turn the V and I control knobs. Move the Recall Switch (10) to P1, P2 or P3. The V and I settings of P1, P2 or P3 will be shown on the display.

6.3.3 To reset the unit back to the factory preset setting...

See section 7.10

6.4 Remote Control Mode

To control the output voltage and current by remote control connector (11), refer to section 8.

7. USING THE POWER SUPPLY

7.1 Besides the HCS-3150, each HCS voltage range has five models. Always check the maximum ratings on the front or back of the power supply. The different output voltage and current ranges are as follows... (x= 1, 2, 3, 4 or 6).


Model Number	Output Voltage Range	Maximum Output Current
HCS-3150	1 ~ 18V	15A
HCS-3x00	1 ~ 16V*	10A, 20A, 30A, 40A, 60A
HCS-3x02	1 ~ 32V*	5A, 10A, 15A, 20A, 30A
HCS-3x04	1 ~ 60V	2.5A, 5A, 8A, 10A, 15A

* Maximum voltage for HCS-3100 & HCS-3200 series is 18V and 36V

7.2 Check the rating label of the power supply and make sure it complies with your AC mains voltage. Connect the power supply to the AC Mains using the power cord provided.

Make sure the Mode Switch (9) is set to the Normal Position.

7.3 The power supply will perform a series of self-checks when switched on. The LED display will indicate the test being performed according to the following sequence. When the cooling fan is checked, the fan will operate at maximum speed and the fan's operation will be heard. After the self-checks (with no load connected) the CV LED and the front panel display light up showing voltage and 0.0 current. To check the set current level, just turn the current control knob one click in either direction. The current display will return to 0.0 after a few seconds.

Self-test display and Sequence	Test contents
	Firmware version
	Display Segment check
	C.V. Indicator check
	C.C. Indicator check
	Rear Control indicator check
	Return to C.V.
	Start of test
	Over voltage protection check
	Over load protection check
	Over temperature protection check
	Fan check
	Output off

7.4 Using the control knobs

The rotary encoder control knobs have fine and coarse tuning with positive clicking action. Push the knobs to toggle between coarse and fine tuning, notice the subtle changes in brightness of the related LED display. Adjust the knobs to your desired values by using coarse and fine tuning as necessary. The display will resume its normal brightness after a few seconds and display the actual output voltage and current.

7.5 Connect the equipment to the power supply. Red (+) is connected to the positive polarity input of the equipment and Black (-) is connected to the negative polarity input of the equipment.

7.6 Switch on the power supply and the panel meter and the green CV Indicator should light up.


7.7 Switch on the equipment and the panel meter and the green CV Indicator should still remain illuminated. You can now operate the equipment. If excessive current is being drawn then the red CC Indicator will illuminate.

7.8 When finished, switch off the equipment and then switch off the power supply. Always switch off and remove the mains plug when the power supply is not being used.


7.9 Manually zeroing the Current Meter Offset (firmware version 3.1 and above)

The power supply will auto-zero the current meter offset when powered up. To reset the current meter to zero during operation, without restarting the power supply, the MENU mode is used.


Press and hold the Voltage Control Knob for 30 seconds to enter the MENU mode. The display then shows:




The Current meter is showing “no” at this time. Rotate the Current Control Knob until the Current meter shows “YES”.



Press the Current Control Knob once to confirm. The “YES” becomes brighter after a successful zeroing of the current meter offset.




Finally, press the Voltage Control Knob to exit the MENU mode.




7.10 Resetting the preset outputs P1/ P2/ P3 to the factory default values

Section 6.3 explains how to set the three preset outputs to your preferred values. To reset them to the factory default, you can use the MENU mode as shown following.


Press and hold the Voltage Control Knob for 30 seconds to enter the MENU mode.




When it is showing “CC0”, rotate the Voltage Control Knob until the Voltage meter shows “rPr”.




The Current meter is showing “no” at this time. Then rotate the Current Control Knob until the Current meter shows “YES”.



Then press the Current Control Knob once to confirm. The “YES” becomes brighter after a successful reset of the three presets P1/P2/P3 to the default factory values.




Finally press Voltage Control Knob to exit the MENU mode



7.11 Upper Voltage Limit (UVL) and Upper Current Limit (UCL)

The power supply has Upper Voltage Limit and Upper Current Limit settings. These values are factory set to the maximum values and can ONLY be adjusted by using the USB port and PC software provided with USB versions of the power supply.

When increasing the output voltage setting and reaching the set UVL value, the voltage display will show:




When increasing the output current setting and reaching the set UCL value, the current display will show:



8. ANALOGUE REMOTE CONTROL MODE

There are two methods for the remote control of the voltage and current using the remote control connector (11). Both methods apply a voltage between 0 and 5 Volts to the control pins. One method is to use an external voltage source such as the output from a DAC (Digital to Analogue Converter). The other method is to use the internal +5V DC provided on pin 1 and a 5k Ω potentiometer to provide the 0 to 5 Volts required. Note, with no voltage connected to the Current Adjustment (pin 3) the power supply's output is turned off. Always apply +5V to the Current Adjustment pin for maximum current output capability. For remote control using the USB port, see the HCS Software Manual.

Remote Socket (11) Pin Assignment		
PIN	FUNCTION	REMARK
1	Internal DC +5V	Maximum 50mA Output
2	Voltage Adjust (V)	0 ~ 5V
3	Current Adjust (A)	0 ~ 5V
4	Ground	
5	Output OFF	Connect to Ground to Activate
6	N.A.	
7	N.A.	
8	N.A.	



Using two 5k Ohm variable resistors or potentiometers.

8.1 Remote Output ON/OFF Control

The remote output on/off control can be activated in any mode - Normal, Preset and Remote (analogue and USB).

- By default, Pin 5 is open and the output is on.
- Shorting Pin 5 to Pin 4 (ground) turns the power supply's output off.
- When the output is off, the C.V. & C.C. LED will flash. The current setting of output voltage and current will then be displayed on the front panel.

9. REMOTE VOLTAGE SENSING (HCS-3600 ONLY)


Please take note of the following warnings as incorrect connection and disconnection may damage the power supply.

WARNING:

- Never short the remote sensing leads!**
- Never connect the remote sensing leads in reverse polarity!**
- Always disconnect the remote sensing leads first!**

CONNECTION SEQUENCE:

1. First, connect the equipment to the output terminals.
2. Second, check that all connections are secure.
3. Third, connect the remote sensing terminals (8), with the correct polarity, at the remote location.



The remote sensing wire gauge should be at least 22AWG.

DISCONNECTION SEQUENCE:

Disconnection is the reverse of the connection sequence above.

10. FAULTS AND TROUBLE SHOOTING

10.1 OVP: Over Voltage Protection

All units have a built-in tracking Over Voltage Protection (OVP) feature. In the event of the output voltage becoming significantly greater than the set value (due to a failure of the power supply's regulation or due to an externally applied voltage), the output will shut down and the following warning appears on the display.



To reset the power supply, switch off the unit and remove all loads. Switch the unit back on again and normal operation should resume. If this problem persists, please contact your agent.

10.2 OTP: Over Temperature Protection

A sensor inside the power supply monitors the temperature and prevents the unit from becoming too hot. When Over Temperature Protection triggers, the output power will shut down and the following warning will appear on the LED display. On receiving this warning, switch off the unit and remove all loads.



Allow the unit to cool down for 30 minutes. Check that the ambient temperature is within specifications. Check if any of the vents are restricted or blocked. Also check that there is sufficient clearance around the power supply. Listen carefully for the noise from the cooling fan when the unit is turned on. If the noise from the fan does not occur during power-up, the fan is faulty, do not use the power supply and contact your agent.

10.3 OLP: Over Load Protection


Normally the CC constant current mode controls the maximum current output of the power supply, should this fail and the maximum current output of the unit be exceeded then the Over Load Protection is triggered. The OLP minimizes the extent of damage to your load and to the power supply. Switch off the power supply as soon as the following warning appears.



To reset the OLP warning, switch off the unit and remove the load. Switch the unit on again and cautiously check that the power supply responds as normal. If this problem persists, contact your agent.

10.4 S1 ERR and S2 ERR: Rear Switch Error

The S1 ERR (RECALL switch) or the S2 ERR (MODE switch) warnings may occur when switching between preset voltages or modes using the rear switches. If error persists, check that the RECALL and MODE switches are in the required positions. To enable the front panel controls both rear switches should be in the top position and the Rear Control Indicator off.



The ERR warnings will turn off and the power supply will return to normal operation once the problem has been removed. If this problem persists, contact your agent.